

34800 BENNETT, FRASER, MI (800) 563-8006 WWW.MPPUMPS.COM STAINLESS STEEL CENTRIFUGAL PUMP

FMX75

INSTALLATION, OPERATION, AND REPAIR MANUAL



Model FMX75 is a high performance, self priming, 316 stainless steel centrifugal pump. The pump is ideal for marine, industrial, agricultural or commercial applications where suction lift is required.

The FMX75 model features all 316 stainless steel components for superior corrosion resistance when pumping chemical compounds. A carbon/ceramic/ Viton bellows seal is standard. Ports are 3/4" NPT with a 1/8" NPT fill port. The FMX75 is capable of 12 ft. suction lift (3450 RPM).

GENERAL SAFETY INFORMATION:

THE FOLLOWING WARNINGS ARE USED TO NOTIFY AND ADVISE THE USER OF THIS PRODUCT OF PROCEDURES THAT MAY BE DANGEROUS TO THE USER OR RESULT IN DAMAGE TO THE PRODUCT.

THIS BULLETIN MUST BE READ COMPLETELY BEFORE INSTALLING, OPERATING, OR SERVICING THE PUMP.

- •**DO NOT** perform service or maintenance when the pumping system is pressurized. Injury or death may occur.
- •**DO NOT** operate the pump in a manner which it was not intended to be used.
- •DO NOT mount the pump such that high piping loads exist on the pump flanges, or in a rigid piping system that does not allow the pipe to expand and cause the pump to be strained.
- •**DO NOT** continue to operate the pumping system when a known leak exists.
- •**DO NOT** continue to operate the pump when unusual noise or vibration occurs.
- •**DO NOT** continue to operate beyond the pressure or temperature limits stated in the product literature.
- •**DO NOT** allow severe temperature changes to occur in a short time period within the pumping system.

INSTALLATION:

For optimum performance, place the pump as close to the liquid as possible to minimize suction lift. For best results, the pump should be installed no more than 10 feet above the liquid supply. The motor is splash resistant, not submersible, and should be located in a dry environment.

Piping /Mounting:

The pump inlet is 3/4" NPT pipe connections. Use pipe sealant The FMX75 is a self priming centrifugal pump and only on the threads. Do not rigid mount both of the flanges and the base to avoid mounting tolerance that may distort the motor base. Install the pump with the shaft in a horizontal direction. Never install the pump with the motor below the pump.

Electrical:

or circuit breaker. See NEC code for the proper minimum wire size for each voltage app-location. Make sure that the pump has the proper voltage rating to match the installation power. Do not use or install if the voltage on the label is different than the installation. All the wire connections must be secure and sealed to protect against arcing.

Operation:

requires priming prior to its initial start up. This is accomplished by removing the fill plug and filling the pump housing with liquid. The pump will retain sufficient liquid for self priming thereafter.

Repair and Maintenance:

The motor must be protected from over current by using a fuse. The pump has a carbon/ceramic seal that may last several thousand hours based upon the application. If the motor is replaced, the mechanical seal should be replaced. A seal that leaks will show leakage between the pump adapter and the electric motor. Extreme leakage could damage the motor bearings and contaminate the inside of the electric motor if left unchecked. Replace any worn or damaged parts.

ASSEMBLY INSTRUCTIONS:

1. Stationary Seal Assembly

From the suction side of the housing # 3, press the stationary seal # 2 into the adapter. Make sure this seal face is sitting flush with the bottom of the bore in the housing.




2. Housing to electric motor Assembly

Slide the housing onto the electric motor #7 pilot. With a 8mm open wrench, tighten the four #5 capscrews.(6-9 ft lbs)




3. Rotating Seal Assembly

Place the rotating portion of the seal onto the shaft of the electric motor or pedestal pilot.
Carbon faces the ceramic as shown.



5. Wear Plate / Flapper Assembly

Place wear plate #13 into the housing as shown. Install #12 snap ring into the groove to secure wear plate to the housing. Place flapper #11 with dimple out as shown.



4. Impeller Assembly

Align the flats of the impeller #1 with that of the electric motor. Press down on the impeller and tighten acorn nut #14 by hand. Place screw driver between a blade and the cutwater of the housing to stop rotation. With a 7/16" socket, tighten the acorn nut the rest of the way. (6-9 ft-lbs)



Place the #10 suction cover onto the housing. Using a 7/16" socket, tighten (6-9 ft. lbs.) (5)



